

INSTRUCTION SHEET

16200108

Description: Antenna Kit - Bottom #14129065

Contents: 1 – Antenna	1 – Gear
1 – Shaft	2 – Rivets
1 – Washer	1 – Retainer, Gear
1 – RTV Scrapper	1 – RTV Sealant
	1 – Instruction Sheet

Procedure:

1. Remove ceramic tray.
 2. Lay oven on its left side and open door.
 3. Remove bottom access cover.
 4. Insert flat blade screwdriver under gear retainer and pry gear retainer from antenna shaft. Discard old gear, washer, and gear retainer.
 5. Inside cavity, remove two rivets securing antenna to cavity and discard old rivets.
 6. Pull antenna from shaft.
 7. Remove shaft from inside of cavity and discard old shaft.
 8. Install new shaft from kit into hole in bottom of cavity.
 9. With raised rib on edge of washer facing away from cavity, push washer over shaft.
 10. With raised rib on gear facing towards cavity, press gear over shaft end tabs until gear snaps into place ("D" shaft).
 11. Install gear retainer onto gear.
- NOTE:** During remaining steps, use caution when handling antenna to prevent antenna damage.
12. Align new antenna over antenna shaft ("D" shaft) and push onto shaft.
 13. Push two rivets from kit thru antenna support into holes in cavity.
 14. Re-install bottom access cover and place oven in upright position.
 15. With door open, plug-in oven and observe antenna operation. Antenna blade should be level with cavity bottom.
 16. Reseal ceramic tray using RTV sealant and scraper (supplied).

