

INSTRUCTION SHEET

16200119

Description: Touch Panel Assembly - Top

Contents: 1 – 59001225 – Touch Panel Assy- Top
1 – 16200119 – Instruction Sheet

Programming WDYRC22 Pads:



- The graphics on this replacement touch panel may be different than the original equipment.
- Refer to the illustrations above for the location of the hidden keypads.